

Getting started with your new Plunger Velocity Diagnostic Kit



Set up Adapter:

1. Plug the USB cable into your Windows based computer. Device drivers will automatically install. Once installed successfully, your PC will display a message that the device is ready to use.
2. Install ETC's Vision Device Management Software from <http://etcorp.ca/engineered-solutions/device-management/>
3. Open Vision software on your computer and navigate to the Setup tab.
4. Under Connection you should see an item in the list called USB Serial Port (COMx). If you do not see this, click refresh. Do not press 'Connect' until Sasquatch is connected to Link.

Set up Sasquatch:

1. Set the Mode on the back of Link to 1 for Sasquatch ([Click for photo](#))
2. Plug the Sasquatch cable into Sasquatch and the other end into Link. ([Click for photo](#))
3. Ensure that the switch on Sasquatch is set to Program Mode (0). ([Click for photo](#))
4. Select Sasquatch from the drop down menu in Vision.
5. Click Connect.

Test the Capture feature in Vision:

1. Select the tab called Capture.
2. Follow the Prompts in Vision.
3. Click Start.